

# Lecture 5

# Satellite Systems





# Topics

1. Introduction to Satellites
2. How do Satellites work?
3. Satellite vs. Ground Communication
4. Satellite Footprint
5. Satellites Types by Bands
6. Satellites Types by Orbits
7. Satellites Applications

# 1. Introduction to Satellites

- A **Communications Satellite** is an artificial object that relays and amplifies radio telecommunications signals via a transponder; it creates a communication channel between a source transmitter and a receiver at different locations on Earth.
- Communications satellites are used for television, telephone, radio, Internet, and military applications
- A satellite travels in a special path, called its orbit.



## 2. How do Satellites work?

- Two Stations on Earth want to communicate through radio broadcast but are too far away to use conventional means.
- The two stations can use a satellite as a relay station for their communication.
- One **Earth Station** transmits the signals to the satellite. **Up link frequency** is the frequency at which Ground Station is communicating with Satellite.
- The satellite **Transponder** converts the signal and sends it down to the second earth station. This frequency is called a **Downlink frequency**.
- The area which receives a signal of useful strength from the satellite is known as the **satellite's footprint**.

# 3. Satellite vs. Ground Communication

## Advantages


The advantages of satellite communication over Ground communication are:

- Greater coverage area
- Transmission cost of a satellite is independent of the distance

## Disadvantages

The disadvantages of satellite communication are:

- Launching Cost is too high
- Larger propagation delay





# 4. Satellite Footprint


**Satellite Footprint**: is the ground area that Satellite covers.

In geostationary orbit, communications satellites have direct line-of sight to almost half the earth - a large "footprint" which is a major advantage.


Dish sizes: 50 cm 60 cm 75 cm 90 cm 120 cm



# Heights of Space Objects



# Height of Geo-Stationary Satellite








# Commercial Communications Satellites Geosynchronous Orbit

- DRIFTING:**
- LMI AP 2 (inclined 30°)
  - BADR-3
  - Galaxy 15
  - Inmarsat II F-2 (i)
  - Nahrul-1
  - Astra 1F
  - Least F-3 (i)



## 5. Satellites Types by Bands


<i>Band</i>	<i>Downlink, GHz</i>	<i>Uplink, GHz</i>	<i>Bandwidth, MHz</i>
L	1.5	1.6	15
S	1.9	2.2	70
C	4.0	6.0	500
Ku	11.0	14.0	500
Ka	20.0	30.0	3500

# Satellite Frequency Bands

- The three most commonly used satellite frequency bands are:
  1. C-band
  2. Ku-band
  3. Ka-band
- C-band and Ku-band are the two most common frequency spectrums used by today's satellites.
- There is an inverse relationship between frequency and wavelength--when frequency increases, wavelength decreases and vice versa.
- As wavelength increases (and frequency decreases), larger antennas (satellite dishes) are necessary to gather the signal.

# C -Band

- C-band satellite transmissions occupy the 4 to 8 GHz frequency range.
- These relatively low frequencies translate to larger wavelengths than Ku-band or Ka-band.
- These larger wavelengths of the C-band mean that a larger satellite antenna is required to gather the minimum signal strength, and therefore the minimum size of an average C-band antenna is approximately 2-3 meters in diameter.



# Ku - Band

- Ku-band satellite transmissions occupy the 11 to 17 GHz frequency range.
- These relatively high frequency transmissions correspond to shorter wavelengths and therefore a smaller antenna can be used to receive the minimum signal strength.
- Ku-band antennas can be as small as 18 inches in diameter.




# Ka - Band

- Ka-band satellite transmissions occupy the 20 to 30 GHz frequency range.
- These very high frequency transmissions mean very small wavelengths and very small diameter receiving antennas.
- The Antenna Diameter can range from 74 cm to 120 cm



## 6. Satellites Types by Orbits

- LEO (Low Earth Orbit)
- MEO (Medium Earth Orbit)
- GEO (Geostationary Earth Orbit)



# Low Earth Orbit (LEO) Satellites

- A low Earth orbit (LEO) is an orbit with an altitude between 160 to 2,000 Kms.
- At 160 km, one revolution takes approximately 90 minutes.
- The majority of satellites, have been in LEO.
- **Earth observation satellites** and **spy satellites** use LEO

## Advantages:

- Better signal strength
- Short propagation delays (10 – 15 msec)
- Low transmission power
- Low price

## Disadvantages:

- A network of LEO satellites is needed, which can be costly
- Small coverage spot
- High system complexity



# Medium Earth Orbit (MEO) Satellites

- MEO is in the region of space around the Earth between 2,000 to 36,000 Kms.
- Used for **GPS**, **communication**, and **space environment science**.
- Average orbital period of 12 hours, as used, for example, by the **(GPS)**.

## Advantages:

- Larger coverage than LEO.
- Fewer are needed than a LEO network.

## Disadvantages:

- Longer time delay and weaker signal than a LEO


# Geostationary Earth Orbit (GEO)

- **Geostationary Satellite**: is orbiting at the same speed as the Earth rotates, but it orbits around the equator and the earth station antenna can be pointed permanently at the position in the sky where it stays.
- From the Earth's surface, an object in a geostationary orbit looks like it is not moving at all.
- GEO is a circular orbit about 35,786 km above the Earth's equator.
- **Communications satellites** and **weather satellites** are often given geostationary orbits, so that the satellite antennas that communicate with them do not have to move to track them,.

# Advantages and Disadvantages of GEO Satellites

## Advantages:

- A large coverage area, almost a fourth of the earth's surface.
- A 24 hour view of a particular area.
- Used for TV broadcast and other multipoint applications.
- Only 3 satellites in Geostationary orbit can cover the entire globe.



## Disadvantages:

- Weak signal and a time delay in the signal
- Have difficulty in broadcasting signals near polar regions

# 7. Satellites Applications

## **1. Communication satellites**

- Communications satellites allow radio, television, and telephone transmissions to be sent live anywhere in the world.

- 1- TV and Radio broadcast

- 2- Internet VSAT Systems

- 3- Mobile Satellite Communications

## **2. Astronomy satellites**

- A big **telescope** in space and used for space observation.

## **3. Atmospheric studies satellites**

- Used to study the Earth's atmosphere

## **4. Navigation satellites**


- Used to determine location of any object like GPS

## **5. Weather satellites**

- Used to find out the weather anywhere in the world any time of the day.

# How does GPS work?

1. The receiver picks up the signals from the satellites
2. Uses the signal travel time to calculate distances to the satellites
3. Triangulates to determine position of the receiver



# Typical Satellite Modem Specs

<b>Network Topology</b>	Star	
	<i>Downstream</i>	<i>Upstream</i>
	<u>DVB-S2</u>	<u>Adaptive TDMA</u>
<b>Modulation</b>	QPSK, 8PSK, 16APSK, 32APSK	BPSK, QPSK, 8PSK
<b>FEC</b>	LDPC, 1/4 - 8/9	2D 16-State, 1/2 - 6/7
<b>Max. Symbol Rate</b>	1 - 45 Msps	128 ksps - 7.5 Msps
<b>Max. Info Rate</b>	149.7 Mbps	19.2 Mbps
<b>Max. IP Data Rate</b>	59.2 Mbps	16 Mbps
<b>Spread Spectrum (Max Rate Mcps)</b>		Up to 7.5 Mcps Spreading Factors: 2, 4, 8
<i>Max rates are achieved under optimal conditions.</i>		